

RU

Памятка по сборке системы
Wind Protection

EN

Wind Protection
system assembly guide

FR

Fiche d'instruction d'assemblage du système
Wind Protection

DE

Bauanleitung zum system
Wind Protection



PL

Instrukcja montażowa systemu
Wind Protection

UA




Пам'ятка зі збирання системи
Wind Protection








2.a

RG/WP +
2 x (DIN 7504 ST3.9x19-O-H)




2.b




RG/WP +
2 x (ISO 7050 ST3,5x19-C-H)





3.a






3.b





5

3 x (ISO 15977-4x10-AIA/St-L)



6

